



1. ALWAYS START CAPPING WALL FROM THE LOWEST ELEVATION
2. CUT CAPS TO FIT. OCCASIONAL CUTTING WILL BE NECESSARY FOR RADII OTHER THAN APPROXIMATELY 7.25 FEET
3. ALTERNATE SHORT AND LONG CAP FACES EVERY OTHER CAP TO ACHIEVE A STRAIGHT ROW OF CAPS
4. USE EXTERIOR-GRADE CONSTRUCTION ADHESIVE TO SECURE CAPS
5. LAY OUT CAPS PRIOR TO USING ADHESIVE



Anchor Wall Engineering, LLC
5959 Baker Road, Suite 390
Minnetonka, MN 55345

These graphic representations are intended for preliminary design purposes only and are not to be used for construction without the signature of a registered professional engineer.

© 2012 Anchor Wall Engineering, LLC
® and ™ Anchor Wall Systems, Inc.

Drawn By: AWE

Date: 3/1/2012

Scale: 1/2"=1'-0"

Drawing Title:

Bayfield® Multipiece Wall System
Capping Details

Project Information:

Typical Details For
Conventional Retaining Walls