



1. Always start capping wall from the lowest elevation
2. Lay out caps prior to using adhesive
3. Cut caps to fit. Various combinations of long and short cap faces will be necessary for radii greater than the minimum.
4. Alternate short and long faces every other cap to achieve a straight row of caps.
5. Use exterior-grade construction adhesive to secure caps.



Anchor Wall Engineering, LLC
 5959 Baker Road, Suite 390
 Minnetonka, MN 55345

These graphic representations are intended for preliminary design purposes only and are not to be used for construction without the signature of a registered professional engineer.

©2008 Anchor Wall Engineering, LLC
 ® and ™ Anchor Wall Systems, Inc.

Drawn By: AWE
 Date: 3/18/2008
 Scale: NONE

Drawing Title:
 Project Information:

Diamond® Retaining Walls
 Cap Block Details

Typical Retaining Wall Details
 www.anchorwall.com