



1. PLACE UPPER BLOCK APPROXIMATELY 1.125" BEHIND LOWER BLOCK
2. INSTALL PINS IN THE SIDE GROOVES OF UPPER BLOCK ENSURING THAT THEY ENTER THE REAR CHANNEL ON THE LOWER BLOCK
3. PUSH UPPER BLOCK FORWARD TO ACHIEVE PROPER 10.6° SETBACK



© 2017 Anchor Wall Engineering, LLC
 © and ™ Anchor Wall Systems, Inc.
www.anchorwall.com

This drawing is for illustrative purposes only and should not be used for construction without the signature of a registered professional engineer.

Sterling™ Retaining Wall System

Pin Installation

Scale:
1" = 1'-0"

Drawn by:
SB

Date:
9/21/2017

Drawing number:
SRST35