


Corners—Outside 90° With Reinforcement

SINGLE-PIECE SYSTEM INSTALLATION INSTRUCTIONS


FIRST COURSE WITH REINFORCEMENT

Begin by checking the wall plan to determine reinforcement lengths and elevations. Lay a section of reinforcement near the corner of the wall, ensuring that it's placed within 1 inch of the face of the block and running along the back of the adjacent wall.



ADDITIONAL COURSES

Lay the next course of block, backfill and compact. When installing the next section of reinforcement, place within 1 inch of the face of the block and running along the back of the adjacent wall. Alternate the reinforcement extension on each course where reinforcement is required.



© 2012 Anchor Wall Systems, Inc. Anchor™ retaining wall systems are manufactured under license from Anchor Wall Systems, Inc. (AWS). The "Anchor Build Something Beautiful" logo is a trademark of AWS. The wall system blocks are covered by the AWS Limited Warranty. For a complete copy, visit your local dealer or see anchorwall.com. All rights reserved.

Anchor Wall Systems, Inc., 5959 Baker Road, Suite 390, Minnetonka, MN 55345.
A&B0925 72.3512.1 08/12 4023