

- 1. ALWAYS START CAPPING WALL FROM THE LOWEST ELEVATION.
- 2. LAYOUT CAPS PRIOR TO USING ADHESIVE.
- 3. CUT CAPS TO FIT. VARIOUS COMBINATIONS OF LONG AND SHORT CAP FACES WILL BE NECESSARY FOR RADII GREATER THAN THE MINIMUM.
- 4. ALTERNATE SHORT AND LONG CAP FACES EVERY OTHER CAP TO ACHIEVE A STRAIGHT ROW OF CAPS.
- 5. USE EXTERIOR-GRADE CONSTRUCTION ADHESIVE TO SECURE CAPS.



© 2018 Anchor Wall Engineering, LLC
® and ™ Anchor Wall Systems, Inc.
www.anchorwall.com

This drawing is for illustrative purposes only and should not be used for construction without the signature of a registered professional engineer. Diamond Pro® 9D Straight II Face Retaining Wall System

Capping Detail

Scale: Drawn by: SB

Date: Drawing number: 11/5/2018 Drawing number: DP9ST202