

Curves—Outside With Reinforcement

SINGLE-PIECE SYSTEM INSTALLATION INSTRUCTIONS

Most retaining walls are designed assuming 100 percent coverage of the reinforcement. When building an outside curve, the block edges of the reinforcement will have gaps and the back edges don't overlap. In order to ensure 100 percent coverage, additional lengths of reinforcement are used to fill those gaps on the next course of blocks. Don't overlap the grid on one course.

FIRST COURSE WITH REINFORCEMENT

Cut reinforcement to the required lengths specified in the wall plan. Lay sections of the reinforcement within 1 inch of the face of the wall with the strength direction perpendicular to the wall face. Avoid overlapping the reinforcement by separating each section.

NEXT COURSE



Place the next course of blocks, marking the backs of blocks to identify unreinforced areas. This step is important because when this course is backfilled, it's impossible to locate the unreinforced areas. Use the marked blocks as a guide, placing subsequent sections of reinforcement to overlap the gaps left on the previous course. This will ensure total reinforcement coverage.

ADDITIONAL COURSES

Repeat this procedure throughout the construction of the curve when reinforcement is required.

MINIMUM RADIUS

Each product has a unique radius. Check the Product Information on anchorwall.com.



© 2012 Anchor Wall Systems, Inc. Anchor™ retaining wall systems are manufactured under license from Anchor Wall Systems, Inc. (AWS). The "Anchor Build Something Beautiful" logo is a trademark of AWS. The wall system blocks are covered by the AWS Limited Warranty. For a complete copy, visit your local dealer or see anchorwall.com. All rights reserved.

Anchor Wall Systems, Inc., 5959 Baker Road, Suite 390, Minnetonka, MN 55345.
A&B0925 72.3516.1 08/12 4023